

Liners

Provide additional warmth and comfort



#94066

#91077 10" Thermashield® Liner (Men's sizes 7-13) Fits: Terra-Lites®

#94055 11" Thinsulate® 3M Liner (Men's sizes 6-15) Fits: Tundra

#94066 16" Borg Liner (Men's sizes XS-XL) Fits: All PVC Boots (Shown)

#99021 5-lbs. Wool Felt Liner (Men's sizes 7-14) Fits: Wolf Pac



BORG LINER SIZING:

Men's Boot Size	Liner Size
4-5	Extra Small (XS)
6-7	Small (SM)
8-9	Medium (MD)
10-11	Large (LG)
12-13	Extra Large (XL)

Replacement Insoles

Provide additional cushion protection



#91080
#91090

#91019 Men's Standard Cushion
(Men's sizes 4-13)

#91080 Softstep 2 (Two Layer Formed Insole)
(Men's sizes 4-16)

#91090 Softstep 3 (Three Layer Formed Insole)
(Men's sizes 5-17)

#91099 SoftStep Xtreme (Arch supporting
Insole) Men's sizes 5-15)



#91099



#91019

22

**Order
Toll Free
1-800-
365-2282**

