

FIT TESTING

For most applications a qualitative fit test will be sufficient. Irritant Smoke creates a positive reaction of coughing if there is breakthrough. Bitrex uses a nebulizer to spray a bitter substance inside a hood. Since Bitrex requires N95 type filters, it is the preferred method for qualitatively fit testing disposable filtering facepieces (dust masks). It can also be used to fit test the CFR-1 and the 7190.

Which Fit Test Method is Best for You?

Qualitative Fit Test Kits

A choice of portable fit test kits is available for fitting employees in the right size mask using qualitative fit testing. Select from Irritant Smoke or Bitrex® kits. Deluxe kits include a hard case. The Irritant Smoke Deluxe Kit also includes a training video. The VeriFit® irritant smoke kit features a handy cassette and includes 10 easy to use, plastic smoke tubes.

Quantitative Fit testing

Quantitative Fit testing provides an absolute number, telling you how well a mask fits on an individual. These tests can be performed using either a particle count such as the TSI Porta-Count® or a negative pressure method.

Quantitative Fit Test Kit for CFR-1

The CFR-1 fit test kit contains one each of small, medium and large 4200 masks, probed to perform quantitative fit testing. 100 refresher wipe pads plus extra suction cups and tubes for fit testing are also included. The rugged storage case keeps contents secure and readily available when needed. The 4200QNKT is used in conjunction with a PortaCount® fit tester with the N95 companion.

**Economy Fit Test Kits are not available in U.S. or Mexico*

North Fit Test Kits

SKU	Description
193120	Saccharin fit test kit
770039E	Bitrex fit test kit, economy
770039	Bitrex fit test kit, deluxe
770046	Irritant smoke fit test kit, 6 smoke tubes
770040E	Irritant smoke fit test kit, economy
770040	Irritant smoke fit test kit, deluxe
193140	Isoamyl Acetate (IAA) fit test kit
194040	Isoamyl Acetate (IAA) fit test kit, deluxe

Quantitative Fit Test Adapter

SKU	Description
770021	For North 5500, 7700, 5400 and 7600 Series facepieces

Sperian Fit Test Kits

SKU	Description
420025	Quantitative fit test adapter for Opti-Fit facepieces with S-Series cartridges
769095	Quantitative fit test adapter for Opti-fit CBRN gas mask



193120



770039E



770040E



194040

Call Customer Care at 800 430-5490.

Call Customer Care at 800 430-4110.